
ModelSmart 3D

The Setup:

- Make sure your work space is bigger than your bridge
 - o Edit
 - Preferences
 - Set your x, y, and z axis to be bigger than your model by 1" on each side
- Views
 - Up and down arrow keys = Zoom in and out
 - Left and right arrow keys = Rotate screen
 - \circ + and on the number pad = Tilt screen
 - o To shift your screen, 2-down, 4-left, 8-up, 6-right
- Have a paper copy of your model for reference
 - With the paper copy, make a graph stating the points of each joint of the bridge and add 1 to every "y axis" point

The Bridge:

- Add a joint
 - O Place anywhere within the rulers
- Joints
 - O CHANGE THE ORIGINAL JOINT COORDIANTES:
 - Joint \longrightarrow Properties \longrightarrow Select the joint \longrightarrow put in the correct coordinates \longrightarrow Apply
 - Then add another joint and put in the coordinate s for that point, etc.
 - DO NOT have 2 joints at the same coordinates, it will mess up your entire model, if the next 4 steps do not work, check for duplicate joints
- The other side
 - Create another joint for the other side of the bridge (, add to the z plane)
- x/y plane
 - O Guides → XY Guide plane → Move plane to joint → Left click on only one of the joints




- Reflect the Points
 - O Guides → XY Guide plane → Replicate joint(s) and move plane to joint → left click the lonely joint
- Members/ Connectors
 - Members → Add → Left click on a joint and hold as you move to another joint, release when your cursor is on the next joint

Testing and analysis:

- Adding Load
 - Loads \longrightarrow Set default forces \longrightarrow Set the values to, X value = 0, Y value = -1, Z value = 0
 - Loads → Add/Change force Y → Left click the bottom middle joints, make sure the arrows are pointing down

Abutments

- Add universal hinge and put it on 2 end joints on one side of the bridge
- Add a XZ roller on the other side of the bridge
- Analysis
 - Make sure all of the following are selected
 - O Analysis → analysis options → color failed members
 - O Analysis → analysis options → Consider → only have axial stresses selected
 - o Include self-weight
 - Find breaking force
- Test
 - \circ Analysis \longrightarrow Run the analysis



Add Universal Hinge

Add an XZ Roller

Results:

- Analysis → Global data
 - O This shows you your model weight, and how much load it held
 - O The number of joints, and members
 - O Which members of the bridge failed first